

IP-1614GII

IP Cameras Products Series

User Manual & Installation Guide

Version: 1.0
Date: March 2, 2006

Table of Contents

TABLE OF CONTENTS.....	2
WHAT IS IP CAMERAS?	3
PRODUCT FEATURES	3
2. PHYSICAL CONNECTIONS	4
3. INSTALLATION	4
CONNECT IP CAM TO NETWORK	6
CONNECT POWER SUPPLY	6
HOW TO RESET	6
START YOUR FIRST TIME NETWORK MONITORING	7
HOW TO VISIT THE BUILT-IN WEB	8
ABOUT THE USER INTERFACE OF IP CAM	9
HOW TO CHECK THE FIRMWARE VERSION	9
HOW TO CHANGE THE CONFIGURATIONS	10
HOW TO CHANGE USER LOGO	12
HOW TO DISABLE AND ENABLE USER LOGO	15
USER MANAGEMENT	16
LOG	17
NETWORK	18
VIDEO	19
EVENT	20
4. PRODUCT SPECIFICATIONS	23
MODELS	23
SPECIFICATIONS:	23
5. APPENDIX	25
DICTIONARY	25
USE CGI COMMAND TO SETUP GPIO AND EVENTS	27
How to configure GPIO Process?	27
How to Configure Event Process	27
SCENARIO: USE DI TO TRIGGER EVENT AND SEND IMAGES THROUGH MAIL AND FTP	28
Turn FTP Service on the server	28
Enable DI status to “ON”	28
Turn On FTP and Email	29
Setup Event status	29
Check DI type status	29
Check Event Status	29
Click on DI and you can check your mail box and FTP services	29

1. Product Overview


What is IP Cameras?

IP Cameras is designed for intranet & internet use. Users can view image or change configurations via built-in web server. The two-layer user-validation prevents any illegal user to monitor or change configuration once user validation is enabled


Product Features

IP Cameras	CPU: 32 Bits RISC Processor. 16Mb Flash, 64Mb SDRAM Linux OS TCP/IP network remote Video transmission system High performance JPEG/MJPEG compression Built-in Web sever Built-in DHCP Client Built-in Motion Detection Frame Rate Control Administrator / User level password protection Snapshots On-line firmware upgrade Frame Rate: NTSC: 30 frame/sec
------------	---

2. Physical Connections




Side Panel Connections




Front Panel Connections

IP-R1614GII

3. Installation



Network connectivity check



```
命令提示符
C:\>ping 192.168.1.1

Pinging 192.168.1.1 with 32 bytes of data:

Reply from 192.168.1.1: bytes=32 time<1ms TTL=64
Reply from 192.168.1.1: bytes=32 time<1ms TTL=64
Reply from 192.168.1.1: bytes=32 time<1ms TTL=64
Reply from 192.168.1.1: bytes=32 time<1ms TTL=64

Ping statistics for 192.168.1.1:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 0ms, Average = 0ms

C:\>
```

Please check your network connectivity before you start install the product. Confirm the link status of your LAN is OK. You may try use the following way to check the network.

Assuming you are under Microsoft Windows 2000 desktop, Click on Start button, Programs, Accessories, Command Prompt . Then there will be a blank window appear to wait command input. Please key in the following command to test the network status.

```
C:\>ping 192.168.1.1 [Enter]
```

***Note:** the target IP address given above may be correct in common scenarios, if your network is not configured by IP segment 192.168.1.x, please change the IP Address to a valid address in your local network. Any difficulties please contact your network administrator for assistance.


If your network status is OK, the result of above command should like following

```
Pinging 192.168.1.1 with 32 bytes of data:
Reply from 192.168.1.1 bytes=32 time=10ms TTL=64
```

...


If you have confirmed your network connectivity is OK, Please proceed to next part of installation guide, otherwise, contact your network administrator to recover the problem.

Connect IP cam to network



Connect IP cam to your hub/switch by using a normal RJ45 cable, plug the RJ45 cable into the Ethernet connector locate at the rear panel of the IP cam, another side connect to your hub/switch.


Connect Power Supply




Connect the IP cam and power source with the adapter provided, plug the power adapter into the DC 12V Connector. Once the power status is OK, the LED in red located at the rear panel of IP cam should light-up.

How to reset

Load IP Cam Default Settings



Start your first time network monitoring



Run the "IPLocator" utility, the newly connected IP cam will be listed in the application window. Please remember its' IP address.

Open an Internet Explorer Window input the following address into the address textbox:

http://[IP cam IP Address provided by IPLocator]

After you press on the enter key, the main working interface and video picked by the camera should appear after a short period. The installation steps are completed. You may now start your first network monitoring experience.


Note: when you first time enter the working interface, the browser may ask whether to install a COMWebSurv component, which is used to communicate with our IP cam product, PLEASE CHOOSE YES to install, otherwise the monitoring function may not work.

How to visit the built-in web


Launch your Internet Explorer (I.E. 6.0 or above) first, then type the IP cam's url. (i.e. http://192.168.1.100). The user validation is disabled as default, no login is necessary. The user is same as the system administrator(Default : root/pass).

For the first time user visits the IP Cam, the ActiveX(ATLWebSurvCOM) will be downloaded to the **[Downloaded Program File]**. Be sure to click the button **[Yes]** as below.

Notes: Call your system administrator if you have not enough privilege to download the ActiveX. (i.e. Users should be the administrator to download the ActiveX for Windows 2000/XP operation system)



You can find the ActiveX ATLWebSurvCOM will be downloaded to the **[Downloaded Program File]** folder. The above dialog will pop automatically once new ActiveX is available(i.e. after firmware upgrade)



About the User Interface of IP Cam

The upper window is for company logo display (i.e. This is a generic version. The company logo leaves blank). The left side of the window is the control panel. The right window is for image display. (Please switch to full screen mode when the resolution is set to VGA mode)



How to check the firmware version

Click the WebCam icon and you will read the firmware version



How to change the configurations

The system administrator: root is the one who has the privilege to change system configuration if user validation is enabled. The following window will appear when you click [Options] icon in the control panel (left side of the window). The follow is the description & field definition.

[System]:

Server Info: Server Model and Firmware Version

Device Name: the name of hardware device.

Video Mode: Video Mode (NTSC or PAL)

Time Zone: Time Zone Setting

Display Option

Show Camera Name: Show Camera Name on Display

Show Date Time: Show Date Time on display


Traffic Control: Bandwidth Setting

Others

Load default configuration: Load the factory default.

Reboot: Reboot the hardware remotely.

Firmware Upgrade : Upload & upgrade the IP cam firmware.




[Firmware Upgrade]: Please follow the standard procedure to upgrade firmware.

Step 0: Stop all unnecessary running application in your PC.


Step 1: Uncheck the **[Browse..]** and **[Upload]** motion images in the Motion Detection Setting and reboot the hardware. **Note: You have to make all event setting to be disable, before you do this step.**

Step 2: Upload the firmware: Be sure to upload the correct firmware. Wrong firmware may cause your IP cam malfunction. It's possible to take a few minutes to upload the firmware into memory depending on the network environment. Since too many unknown situation may occur in the Internet, we strongly recommend you to upgrade firmware in the Intranet.



Step 3: Write firmware to your IP cam. It will take a few minutes to write firmware into flash. The IP cam will reboot automatically when writing firmware is complete. Please DO NOT reboot the device manually.

Note: Any interrupt during writing will cause the IP cam malfunction. The UPS may prevent the power failure problem.



How to change User Logo


We allow you to use your own logo from version v3.0. User logo will not be erased when you upgrade firmware in the future. The detailed procedures are as follows:

Step1: Type <http://Video ServerIP/LogoUpload.htm>



Step 2: Browser the logo file to use and upload to upload it.

Note: The file format must be gif and the max size is 30 K bytes.



Step 3: Click [Change] button to write logo file into flash memory.

Change Logo

Note: Please stop all unnecessary running applications in your PC while changing logo.

Click **Change** to change logo

Click **Cancel** to abort.

Click **[OK]** to change really!

Step 4: Reboot Video Server once ChangeLogo is complete.

Change Logo

Note: Please stop all unnecessary running applications in your PC while changing logo.

Click **Change**

Click **Cancel** to abort.

Change Logo

Note: Please stop all unnecessary running applications in your PC while changing logo.


Click **Change**

Click **Cancel**


Step 5: You have to clear the [Temporary Internet files] to take changes effect since there is always some catch in the I.E. Please click [Tools] [Internet Options..] on the top bar.



Step 6: Clear [Temporary Internet files] as follows.



Step 7: Refresh I.E. (Click F5) to take changes effect. You will see you new logo below.



How to disable and enable user logo

Type: <http://Video ServerIP/SetOEM.cgi?LOGO=0> to turn off the user logo



or <http://Video ServerIP/SetOEM.cgi?LOGO=1> to turn on the user logo

User Management

The administrator(root) has the privilege to manage users if User Validation is enabled. Here are the configurations available & field definition.

[User]:

User validation

Yes : Enable user check

No : Disable user check

Add/Modify User: To create new user or modify existing user password


Username : user name

Password: user password

Confirm : user password confirmation

Delete user: To delete existing user

Current User List: The users in the IP cam



Log

The system log will be listed in the window when you click **[Log]** icon.


Operation: The operation which user operates

Value: The value to change

Client IP: The IP address of client PC

Client MAC: The mac address of client PC

Datetime: date-time which operation occurs



Network

Allows administrator(root) to change network setting when you click **[Network]** icon.

IP Setting: Please consult you networking manager for the following values

Manual: To set network setting manually.

DHCP: To let IP cam get network setting from DHCP server automatically.

IP Address: IP address of IP cam

Subnet mask: Subnet mask of IP cam

Default Gateway: Default gateway of IP cam

DNS 1/2/3: DNS Server IP if necessary

Http Port: Change the http port of built-in web server (default 80).

(i.e. range 80, 1025 ~ 65535)

The screenshot displays the 'Options' menu on the left, with 'Network' selected. The 'Network Setting' panel includes the following fields and controls:

Field	Value
IP Address	192.168.2.43
Subnet Mask	255.255.255.0
Default Gateway	192.168.2.21
DNS 1	0.0.0.0
DNS 2	0.0.0.0
DNS 3	0.0.0.0
Http Port	80

Radio buttons for 'Manual' and 'DHCP' are present, with 'DHCP' selected. A 'Submit' button is located at the top right of the form area. A 'COM Port Setting' button is located at the bottom center of the form area.

Video

Allows administrator(root) to change Image Setting, Traffic Control or Motion Detection.

Image Setting

Quality: Image Quality (Low/Normal/Good/Fine/Excellent)

Images Size: 160x120/176x144/320x240/352x288/640x480/704x576

Rotation: Normal/180 degree (Upside down)

Advanced: Image preference adjustment

Brightness: Adjust image brightness

Contrast: Adjust image contrast


Hue: Adjust image hue

Saturation: Adjust image saturation

Traffic Control

Unlimited: To send out image at full speed. (up to 30 frames per second)

Frame per second: Delay to send image every x second(mini-second)



Event

This Option contains three major functions: Server Configuration, GPIO Configuration and Event Configuration

Server Configuration: User can setup Ftp and Mail services that provides the actions in Event setting.

The screenshot shows a web interface titled "Options" with a navigation menu on the left and a main content area. The navigation menu includes System, User, Log, Network, Video, Event (highlighted with a red box), and Home. The main content area has a tabbed interface with "Server Setting" (highlighted with a red box), "DI Setting", "DO Setting", "MSG Setting", and "Event Configuration". The "Server Setting" tab is active, showing "Mail Setting" and "FTP Setting" sections. The "Mail Setting" section includes a checked checkbox for "Mail motion images", a "Submit" button (highlighted with a red box), and input fields for SMTP Server (mail.asip.com.tw), User Name (webcam.asip), Password (checked), Mail From (webcam@asip.com.tw), Mail To (test@asip.com.tw), and Mail Subject (Your Mail Subject). The "FTP Setting" section includes a unchecked checkbox for "Upload motion images" and input fields for Ftp Server, User Name, Password, Account, and Upload Path.

See figure below:

Allows administrator(root) to configure the mail & ftp setting once motion detected

Mail Setting: if check on Mail motion images, Device will send motion images

Mail Server: Name or IP of Mail server

Username: User name

Password: User password (Password will be validated if checked)

Mail From: Mail sender

Mail To: Mail receiver

Mail Subject: Mail subject

FTP Setting: if check on Mail motion images, Web DVR will upload motion images

FTP Server: FTP Server

Username: User name


Password: User password

Upload Path: Images upload path

GPIO Configuration : Allow user to define types of digital input and their status.

See Figure below:

DO Configuration:



Index: the Index of digital output

DO Type: define type of digital input to : **[Normal Open]** or **[Normal Close]**

DO Status: Disable the DO or Enable it.


MSG Setting:

Alert Message function provides user the ability to send message to a remote server. Device manager can assign ip address , port number and message for remote server. Thus, Remote server can collect related alert messages via network when events are triggered.

[IP Address]: Server's IP addresss.

[Port Num]: Http port Number.

[Message]: Message string.



Event Configuration: User can select Event Index to locate Event (range from 0-2) and also decide to enable or disable this event. Three parts of event setting will be discussed below: **[Trigger condition]**, **[Delay time]**, and **[Trigger Action]**

[Source]: The **[Input Type]** contains DI0, DI1 and Motion Detection

[Eanble]: Select to Enable the Input Type that you selected.

[Delay time]: Duration that ignores same event trigger. Range from (1-30) sec

[Action]: Including FTP, MAIL, DO and MSG.

After System accepts trigger condition, related actions can be launched. FTP and MAIL will send image to remote area, thus; [Camera] is necessary for user to specify. DO is related to its index to specify which digital output (Only 0 is enable). MSG can send a string to remote server via TCP protocol which will be released soon.

Options

Server Setting | DI Setting | DO Setting | MSG Setting | **Event Configuration**

System

User

Log

Network

Video

Event

Home

Event Condition

Event: 0 | Source: DI0 | CamID: 0 | Enable
 (Delay: 3 seconds before detecting the next event)

Action

FTP Image | DO: 0
 Mail Image | Alert Message

Submit

Event ID	Source	Action	Cam ID	Enable
0	DI0		0	<input type="checkbox"/>
1	DI0		0	<input type="checkbox"/>
2	DI0		0	<input type="checkbox"/>

Detail List

Action FTP and Mail include Camera ID

4. Product Specifications

Models

IP-R1614II: IP Cameras with serial communication support

Specifications:

Items	Specifications
Model	IP-R1614GII
Power	
<i>Supply</i>	DC 12V , 350mA(MAX)
<i>Consumption</i>	~3 Watts
Networking	
<i>Connectivity</i>	10/100 Ethernet
<i>Protocols</i>	SMTP, FTP, DHCP, HTTP
<i>Internet</i>	Built-In HTTP Web Server, DHCP Client
Event Controls	
<i>Trigger By</i>	Motion Detect
Alarm Notifications	FTP/Mail motion image, Message
Sensor	1/4" CCD Image Sensor
Images	
<i>Compression</i>	JPEG/MJPEG
<i>Bandwidth Control</i>	Frame Rate Controls
<i>Format</i>	NTSC:640x480/320x240/160x120 PAL: 640x480/352x288/176x144
<i>Frame Rate</i>	25 fps @ 320x240 20 fps @ 352x288
<i>Quality</i>	5 Level Image Quality
<i>Image adjustments</i>	Brightness / Saturation / Contrast / Hue
Security Controls	
<i>Access Control</i>	Administrator / User Level Password Protection
<i>Configuration</i>	Http Port configurable
<i>Log</i>	Historical Access Log Management
Operating Environment	
<i>Temperature</i>	5°C~50°C(45°F~125°F)
<i>Humidity</i>	20% ~ 80%

LED Indications	Power, Network
Dimension	60mm(W) x 31mm(H) x 84mm(L)
Remote Viewing	Windows 98/2000/XP IE5.X or above
Lens	
Built-In Lens	3.7mm/F2.0
Cable	100 flexible cable between the mini lens and the IP CAM

5. Appendix

Dictation

TCP/IP:

Transport Control Protocol/Internet Protocol, the protocol used to transmit data between hosts in Internet, which provides data verification and error protection

Web:

World Wide Web service is used on Internet widely, It's provides interactive rich content by using a web browser

Firmware:

A program built in hardware, which is used to control the hardware, provides software level functions

MJPEG:

Motion JPEG compression algorithm, use to compress digital video

MPEG:

International standard video compression algorithm

DHCP:

Dynamic host configuration protocol, used on IP network perform IP address, gateway, DNS server assignment, etc for client computers

DNS:

Domain Name Server/Service is used to translate domain name in to IP address

LAN:

Local area network

WAN:

Wide area network, normally Internet

FTP:

File transportation protocol, used to transmit files between server and client

POP:

Post office Protocol provides Email storage and receive service

SMTP:

Simple mail transportation protocol, provides Email delivery and relay service

Hub:

Physical layer network inter-link device, which simply connect ports together and broadcasting the data packet to all the port.

Switch:

Data link layer network inter-link device, which provides end-to-end data packet forwarding,

Router:

Network layer device, which connect networks and provides the function named "Routing" to find the best way to transport data from source to destination

CGI:

Common gateway interface, a kind of program, running on a web server to provides dynamic data process function and interacts with users' action

ActiveX:

Concept and standard gave by Microsoft, which separates program into functioning pieces named ActiveX Control. These control can be embed into users' program to give their specific function.

Use CGI command to setup GPIO and Events

How to configure GPIO Process?

How to setup DI type in the device

`http://ServerIP/SetDIType.cgi? Channel=<1>& Enable=<FALSE | TRUE>& Type=<"NC"|"NO">`

Example: Set channel 1 (Input channel) into 'NC' type

`http://192.168.2.1/SetDIType.cgi? Channel=1&Type=NC&Enable=TRUE`

How to get DI type in the device

`http://ServerIP/GetDIType.cgi`

How to get DI status into the device

`http://ServerIP/GpioInput.cgi?`

Example: Get channel status from channel 0 to channel 1

`http://192.168.2.1/GpioInput.cgi?`

How to set Do status into the device

`http://ServerIP/GpioOutput.cgi? Value=ON|OF`

Value - 0: LOW

1: HIGH

Example: Set channel 1 (output channel) into LOW

<http://192.168.2.1/GpioOutput.cgi? Value=ON|OFF>

How to Configure Event Process

How to setup event status?

http://ServerIP/SetEvent.cgi?Reset=<FALSE|TRUE>&Index=<Value>&Input_

Type=<0|1>&Enable_Flag=<FALSE|TRUE>&Action_FTP=<ON|OFF>&Action_MAIL=<ON|OFF>&Action_DO=<ON|OFF>&Action_MSG=<ON|OFF>&Action_PRESET=<ON|OFF>

Index=0~2 event index from 0 to 2

Input_Type: 0 = Digital Input, 1 = Motion detection

Enable_Flag:FALSE|TRUE, TRUE=ENABLE, FALSE=DISABLE

Action_FTP=<ON|OFF>

Action_MAIL=<ON|OFF>

Action_DO=<ON|OFF>

Action_MSG=<ON|OFF>

Action_PRESET=<ON|OFF>

Input_index=<Value>

Output_index=<Value>

Reset=<FALSE|TRUE> clean all the event

Example : Setup an Event=> DI trigger "DO" and "MAIL" in first event(that means index = 0)

http://192.168.2.1/SetEvent.cgi?Index=0&Input_Type=0&Enable_Flag=TRUE&Action_FTP=ON&Action_DO=ON

How to get event status?

<http://ServerIP/GetEvent.cgi?Index=<0~2>>

Index=0~2

Example: Get Event index =1

<http://192.168.2.1/GetEvent.cgi?Index=1>

Scenario: Use **DI** to trigger **event** and send images through **Mail and FTP**


This scenario can help you to simulate use our digital input to send Mail or FTP into remote side.

Turn FTP Service on the server

Enable DI status to "ON"

Exp: <http://ServerIP/SetDIType.cgi?Channel=1&Type=NC>

Turn On FTP and Email



Setup Event status

<http://192.168.2.1/SetEvent.cgi?>

Index=0&Input_Type=0&Enable_Flag=TRUE&Action_FTP=ON&Action_MAIL=ON

Check DI type status

<http://ServerIP/GetDIType.cgi>

Channel = 1

Enable = 1

Type = NO

Check Event Status

<http://192.168.2.38/GetEvent.cgi>

Index =0, Input_Type=DI, Enable_Flag=1, Action_Type= FTP MAIL

Click on DI and you can check your mail box and FTP services