



OVER VIEW




A	Power Button	டு
	(Record)	
₿	Menu Button	⊞
6	Up Button	A
9	(Vol+)	\oplus
	Down Button	▼
O	(Vol-)	\ominus
3	Hold switch	
•	Mode Button	
G	Enter Button	\square
U	(Pause/Play)	
0	Left Button	₩
	Right Button	>
J	Snapshot	


Inserting Battery & USB connects:



Browser, Memory, Setup, Modes:


- How to play movies(Movie)?
- 2 How to review your pictures (Photo)?
- 3 How to record voices/sounds (Recorder)?





Browser, Memory, Setup, modes:

- 7 How to review your files?(Browser)
 8 How to select "Internal Memory" or "SDHC Card" (Memony)?
- 9 How to setup the system(Setup)?









AV-IN, TV out modes:

(I) How to record a video clip(AV-IN)?


11 How to connect with TV?



Mini mobile MP4 digital video recorder-MP- 455E




Instruction Drawing & Description





Monitor Dot defect:(Criteria (acceptable))

Total	Area		Total
Total	1	0	iotai
Bright dot defect , Black dot defect	≤ 2	§ 5	€ 6

Date and Time stamping:








AV REC. and Snapshot:





15 How to Snapshot?

